

# Application instructions for the Vision Protect Kit

The single most important variable in controlling the service life of Vision Protect is the preparation of the surface. The treatment will not adhere to a dirty, greasy and wax or silicon contaminated surface. Proper surface preparation will ensure maximum adhesion to the substrate and maximum performance. Even brand new glass has already collected contaminations from production, storage and transport and installation. When you apply an ultra-thin Nano-coating these substances need to be removed.



**1**

Clean the glass surface, remove dust and dirt. Do not apply in hot conditions or on hot glass.



**2**

Open Surface Preparation sachet. Apply on to the glass in small circular overlapping motions. Make sure all glass is covered with the surface preparation.



**3**

Wipe dry the glass and wipe dry all rubber seals, frames and edges. Remove all visible surface preparation residues from the glass. If required use a paper cloth to do so. Glass must be clean and dry prior the next step , the coating application.



**4**

Open the glass coating sachet , take out the Vision Protect sachet. The application of the glass coating should be done quick and steady and instantly after the foil is opened.



**5**

Apply with circular overlapping motion. Make sure the whole surface is treated evenly. Then go back and use the cloth to polish of any residue. Keep polishing until the cloth is dry. Use the second cloth on the other half of the windscreen. Keep polishing until the glass is streak free and crystal clear.



**6**

Vision Protect is water resistant 15- 30 minutes after the application, reaching its optimal repellent effect within 24 hours.